

1150 Blue Mound Rd West #403 Haslet, Texas 76052 Off. (817) 710-5233 Fax (817) 439-8385 www.frctexas.com

# Fire Retardant Coatings of Texas®, LLC FX LUMBER GUARD® INTERIOR FIRE RETARDANT PENETRENT

## TECHNICAL DATA SUBMITTAL

## CERTIFIED FOR FACTORY AND FIELD **APPLICATIONS**

- Fire Retardancy is indefinite if protected from excessive exposure (3-4 weeks) to high humidity of >80% or wet locations.
- Can be stained, painted, or sealed over after material is dry with a water based products only. (Recommendation: apply stain, paint, or sealer to a small area before overcoating to check for compatibility.)
- Treated dimensional lumber can be straight cut or crosscut. If ripping or milling, the cuts will need treating. All sides must be treated (call for exceptions)
- Treated plywood and EWP can be straight cut, crosscut or ripped, and will not require re-treatment.
- · Recommended fasteners: follow IBC Chapter 23, Stainless Steel, Galvanized or Copper

We provide a red colorant for validation of treatment when requested by our customers at no additional cost.

Meets 16 CFR 1500.3 FHSA of the Consumer Product Safety Commission (CPSC) as Non-Hazardous / Non-Toxic

#### CERTIFIED ONE COAT APPLICATION

Design Values of lumber, plywood and OSB are not affected due to the non-invasive application of FX Lumber Guard.

DO NOT ADD ANYTHING TO THE PRODUCT

#### KEEP FROM FREEZING - DO NOT DILUTE

NOTE: The results of the three-listed species (Southern pine, Douglas fir, and either white spruce or a Spruce/Fir mixture) are allowed to be used together to make inference on untested wood species because the three-tested species represent the full spectrum of expected treatability. Ref: ASTM D5516

### **Intertek Certified Listed & Tested**

**ASTM E84 (Class A 10 Minutes)** ASTM E84 / ASTM E2768 (Class A 20 Min. Ext.)

Certified on the following

Southern Yellow Pine, Spruce Pine Fur, Hem Fir & Doug Fir Lumber, Doug Fir & SYP Plywood & OSB

> See the Intertek Directory of Building Products, bpdirectory@intertek.com for complete information.

### Additional Class A Testing, Standards and Certifications

#### CSI Div. 06 05 73.33 Fire Retardant Wood Treatment

ICC ES ESR 3872

ICC ES ESL-1087 and ESL-1064 Cert. ASTM E119 (1 Hour Rated Assemblies) ASTM E119/ULC S101 - 17 Min Res. ASTM D5664 Lumber Strength-High Temp. ASTM D5516 Ply/OSB Strength-High Temp. ASTM D3201 Hydroscopic Properties-19.9% ASTM D2369 VOC Content Tested AWPA E12 Corr. of Metal Non-Corrosive NFPA 259 Potential Heat of Building Materials

IAPMO ER-478 IAPMO UEL-5019 Cert. MEETS NFPA 255 / 703 AC 363 Compliant ANSI / UL723 - UBC 42.1 NFPA 703 Compliant AWPA U1 UCFA Interior UL Green Grd Gold-Certified Certified 1 Coat Application ASTM E84 / ULC S102 Class A

Additional Applications: I-Joist, PSL, LVL, LSL's, Glulam's, Cedar, Redwood, MDF, Particle Board and other porous softwoods / hardwoods & Sheathings. Can be used in 2-hour assemblies where fire retardant lumber and sheathing is required.

#### **TECHNICAL INFORMATION**

FSI <25 • SMOKE 50 - 165 • 3-year shelf • 300-350 Sq. ft. per gallon Non-Toxic ● Non-Hazardous ● Environment Safe Paintable / Stainable / Finish able (with water based products only)

Apply 45-95° F ● Store above 45° F

**LOW VOC EMISIONS AND CONTENT** 

#### **Application Process:**

Material to be treated must be clean (no sealer, stains, or paint) & dry before treating. Agitate FX Lumber Guard before and throughout the application. Apply as you received it, spraying with a hand pump sprayer, a high-volume low-pressure system at a rate of 300-350 sf per gallon depending on the material treated. (Vertical spraying) Start from the bottom and work up as there is less runoff this way, dry time will vary from 8-32hrs depending on air temp & humidity. The maximum moisture content for the substrate to be treated is 15 percent for dimensional lumber, 19 percent for plywood, and 16 percent for oriented strand board (OSB). If you have any questions or concerns, please contact us for answers.

#### Field Testing:

When the observation of the treatment or field testing is required, field testing must be as follows: The treated substrate will not have distinctive observable features. Ensuring the treatment application of the material has been done correctly, a sample of the treated substrate must be tested. The flame from a small fire source (propane torch) can be applied to the treated sample to validate the application of the fire-retardant and an untreated sample of the substrate for comparing the reaction of the surface for not less than 15 seconds. The presence of chemicals must be observable through the comparison of the reactions of the substrates to the flame. Presence of the fire retardant can be observed when it begins to form a black layer of charring.

Finishing: Use a water based, non-acrylic, non-satin finish. FX Lumber Guard needs to be dry before any top coating material is used. When applying a finish, test a small area first to make sure the surface is dry enough and the results are what you want. If gumming or balling of the topcoat is present that means FX Lumber Guard is not dry enough for top coating.

WARNING: KEEP THIS AND ALL CHEMICALS OUT OF CHILDRENS REACH - AS WITH ANY PRODUCT, THIS PRODUCT MAY CAUSE EYE AND/OR SKIN IRRITAION - ALWAYS WEAR PERSONAL PROTECTION EQUIPMENT WHEN HANDLING THIS OR ANY CHEMICALS.























